

DIAMOND ✨

www.wittetools.com.au

WITTE
WERKZEUGE



Grips the
screw head.

diamond coating · fits accurately · abrasion resistant

DIAMOND

DIAMOND PH



drive 1/4"

| Art.-Nr. | mm | | |
|----------|------|----|----------------------|
| 27391 | PH 1 | 25 | C6,3 DIN3126/ISO1173 |
| 27392 | PH 2 | 25 | C6,3 DIN3126/ISO1173 |
| 27393 | PH 3 | 25 | C6,3 DIN3126/ISO1173 |

Bitflex DIAMOND PH



drive 1/4"

| Art.-Nr. | mm | | |
|----------|------|----|--------|
| 27971 | PH 1 | 25 | 6,3 mm |
| 27972 | PH 2 | 25 | 6,3 mm |
| 27973 | PH 3 | 25 | 6,3 mm |

DIAMOND PZ



drive 1/4"

| Art.-Nr. | mm | | |
|----------|------|----|----------------------|
| 27611 | PZ 1 | 25 | C6,3 DIN3126/ISO1173 |
| 27612 | PZ 2 | 25 | C6,3 DIN3126/ISO1173 |
| 27613 | PZ 3 | 25 | C6,3 DIN3126/ISO1173 |

Bitflex DIAMOND PZ



drive 1/4"

| Art.-Nr. | mm | | |
|----------|------|----|--------|
| 28011 | PZ 1 | 25 | 6,3 mm |
| 28012 | PZ 2 | 25 | 6,3 mm |
| 28013 | PZ 3 | 25 | 6,3 mm |

WITTE DIAMOND

The advantage of the micro particle diamond coating is that the WITTE DIAMOND Bit clings into the screw head. Consequently the reduced slipping out from the screw head is multiplied thus ensuring an even better grip. This is especially important when screwing on high value surfaces or those that are easily damaged.



With the diamond coating the WITTE DIAMOND Bit offers maximum fitting accuracy; and combined with the high value gold coating gives an optimal protection against corrosion.

The extremely hard diamond particles make the bit more wear-resistant and considerably increase its durability and endurance. The WITTE DIAMOND Bit is ideally suitable for use in mechanical and automated series screw driving applications.



Available From:



SIEPER & Co. Pty Ltd
Wholesale Distributors
Ph: (02) 9352 0600 | www.sieper.com.au